

WeatherTech[®]

UnderLiner[™] Installation Instructions



- 1** Place UnderLiner[™] in the bed of your truck. Align contours and cutouts for the wheel wells to allow UnderLiner[™] to lay flat and smooth.



- 2** Secure by placing your rigid bed liner on top.

Backed by a Limited Lifetime Warranty

⚠ WARNING ⚠

**UnderLiner[™] is Designed for
Placement Under a Rigid
Drop-in Truck Bed Liner ONLY!**

DO NOT USE OR SECURE WITHOUT A BED LINER

**Questions? Call customer service at 630.769.1500
Monday - Friday: 9 a.m. to 5 p.m. Central Time**