

WeatherTech®

Tailgate TechLiner® Installation Instructions

Thank you for purchasing your WeatherTech® Tailgate TechLiner®. The Tailgate TechLiner® will offer incredible, affordable protection and years of reliable use if you follow these simple instructions



Parts Kit # 88TG08

- (1) T-25 1/4" Insert Bit
- (6) Plastic Shoulder Washers
(you will use only 4)
- (3) Extrusions



Tools required

1/4" Driver



- 1** Lower the tailgate and remove all tailgate accessories prior to installation. Clean your truck bed with soap and water or TechCare® Gentle Car™ Shampoo and dry thoroughly before installing the Tailgate TechLiner®.

**Take note of the location of the Velcro® pads on the bottom of the Tailgate TechLiner®, and prevent the pads from becoming dirty or collecting debris. Do not remove the adhesive backing at this time.*



- 2** Using the appropriate driver and enclosed Torx bit, remove the 4 bolts and washers shown in Fig. 2. Loosen the 4 bolts shown in Fig 3. Do not discard bolts, you will use them in a later step.



67TG08
© 2015 by MacNeil IP LLC

[View Easy Installation Video](#)

WeatherTech.com/install

Questions? Call customer service at 800-441-6287

MacNeil®
AUTOMOTIVE
PRODUCTS LIMITED

Specialists in Original Equipment and
Aftermarket Automotive Accessories
1 MacNeil Court • Bolingbrook, IL 60440
800-441-6287 • 630-769-1500 • fax 630-769-0300

WeatherTech.com

WeatherTech®

Tailgate TechLiner® Installation Instructions



- 3** Remove the 3 plastic extrusions from the parts bag. Starting from one end, place the first extrusion under the edge of the steel panel using the channel as shown. The remaining 2 extrusions will be placed end to end, resulting in 1 extrusion that runs the width of the tailgate.

Tighten the 4 bolts that were loosened previously.



- 4** Tuck the rear edge into the plastic extrusion that you just installed. Next align all of the contours of the custom fit Tailgate TechLiner® to the contours of your tailgate for a seamless fit.



- 5** Position plastic washers from the parts kit on the bolts so the large diameter of the washer goes under the existing washer as shown. Hand tighten all 4 bolts in their original holes first, then tighten each one using the Torx bit. Start with the center 2 bolts first, then the outer two. **DO NOT OVER TIGHTEN.**



- 6** Bend the Tailgate TechLiner® backward to locate the Velcro® discs without shifting the position of the Tailgate TechLiner®. Use the supplied TechLiner® Cleaning Kit to thoroughly clean the areas that will contact the Velcro® discs. Allow tailgate to dry completely before moving on to Step 7.



- 7** Remove the plastic backing from the Velcro® discs and fold the Tailgate TechLiner® back into place. Press down firmly on the location of the Velcro® discs. Take care to not pull apart or peel off the Velcro® discs until you affix them to the tailgate.

WARNING!

NOTE: It is imperative to adhere the Tailgate TechLiner® to the tailgate of the truck as described above. Failure to do so may allow the Tailgate TechLiner® to lift during travel as a result of turbulent airflow, which could result in unsafe conditions for the operator of the vehicle or other vehicles nearby.

Clean your Tailgate TechLiner® using mild soap and water, or use our TechCare® FloorLiner™ & FloorMat Cleaner and Protector for best results.



Specialists in Original Equipment and
Aftermarket Automotive Accessories
1 MacNeil Court • Bolingbrook, IL 60440
800-441-6287 • 630-769-1500 • fax 630-769-0300
WeatherTech.com