



Truck and Jeep Accessories

Instructions for drilling out threads of steel mounts for 2008-2016 Ford Super Duty

TB04060

Note: verify all body mount locations before drilling out steel mount threads

1) Take threaded steel mount



2) Clamp steel mount on vice



3) Bore threaded hole of steel mount with 1/2" drill bit



4) Verify bolt fits through steel mount

