2.0 Shock Guard Install Instructions





5. с.

Apply the appropriate clip to your shock.

may skip this step.

Align the square shape on top of the neck of shock guard with clip. Notice the clip has an identical square shape between the gap. Push neck of shock guard through the gap in the clip until shock guard snaps in place. Note: Daystar shocks (c.) do not require a clip.



Position zip ties toward the top of the shock tube and firmly tighten your zip ties into place. You may cut the excess zip tie with a pair of cutters.

FINISHED









