



Installation Instructions

Part number 861100 & 861101

1. Behind the larger mirrors there are 3 clips holding the cover on to the mirror.
2. There are two upper clips and one lower clip that must be unclipped for the mirror cover to release. *****PLEASE USE CARE WHEN PROCEEDING WITH THE NEXT TWO STEPS SO YOU DO NOT BREAK THE FRAGILE PLASTIC TABS/CLIPS WHICH HOLD THE MIRROR COVER IN PLACE***** - (You will have to move the mirror side to side and up and down to gain access to the clips. The upper clips are located about 3 inches from the top of the mirror. The one lower clip is on the side closest to the truck and about 6 inches below the upper clip.)
3. Using a long flathead screwdriver, push down to remove the clips. (You may need a small flashlight to see behind the mirror itself.)
4. The mirror cover will now release from the mirror.
5. Unplug the wiring harness from the light and remove the cover and light assembly from the truck.
6. Squeeze the two butterfly clips on the inside of the light and push outwards. (Careful not to break the three guide clips on the outer side of the light.)
7. Replace the old lights with the new ANZO lights in reverse order to re-install.
8. Turn the truck on and check for proper operation of both blinkers and running lights.

ANZO warranties against manufacturing defects for 1 year from date of purchase. Return defected product directly to place of purchase with proof of purchase receipt or invoice.

For additional assistance
Please call our customer service at
888.360.3696