



## **Installation Instructions**

### **Part number 861102 & 861103**

To remove your factory turn signal lens you will need to locate the release clip behind the larger, top mirror of your 2008-2010 Ford Superduty. The clip is physically behind the mirror on the horizontal edge, just adjacent to the lens.

1. Push the top, inside of the mirror so that there is a large gap by the bottom, outside edge.
2. You should see the release clip now and you simply need to depress it using a flat head screwdriver. This will release the light from the mirror.
3. Remove the bulb sockets from the factory lens and then remove the bulbs from the sockets.
4. Insert our plugs into the vacant sockets and snap your new ANZO LED mirror lights back into the mirror.
5. Test the running lights and the turn signals to ensure the plug is inserted correctly before snapping the ANZO lens onto the housing.
6. You will need to find a place to accommodate the wire inside the housing before you snap the lens on.

ANZO warranties against manufacturing defects for 1 year from date of purchase. Return defected product directly to place of purchase with proof of purchase receipt or invoice.

For additional assistance  
Please call our customer service at  
888.360.3696