

Owner's Nanua

Banks A-Pillar Mount Gauge Mounting

2011-2016 Ford Super Duty

THIS MANUAL IS FOR USE WITH SYSTEM 63345, 63346, 63347

Gale Banks Engineering 546 Duggan Avenue • Azusa, CA 91702 (626) 969-9600 • Fax (626) 334-1743

Product Information & Sales: (888) 635-4565 Customer Support: (888) 839-5600 Installation Support: (888) 839-2700

bankspower.com

©2019 Gale Banks Engineering

11/04/19 PN 97694 V1

General Installation Practices

Dear Customer,

If you have any questions concerning the installation of your Banks A-Pillar Mount System, please call our Technical Service Hotline at (888) 839-2700 between 7:00 am and 4:00 pm (PT). Watching our how-to video (link on the cover) may alleviate any further questions. If you have any questions relating to shipping or billing, please contact our Customer Service Department at (888) 839-5600.

Thank you.

1. Before starting work, familiarize yourself with the installation procedure by reading all of the instructions.

2. Throughout this manual, the left side of the vehicle refers to the driver's side, and the right side to the passenger's side.

3. Disconnect the negative (ground) cable from the battery (or batteries, if there are two) before beginning work.

4. Route and tie wires and hoses a minimum of 6" away from exhaust heat, moving parts and sharp edges. Clearance of 8" or more is recommended where possible.

5. When raising the vehicle, support it on properly weight-rated safety stands, ramps or a commercial hoist. Follow the manufacturer's safety precautions. Take care to balance the vehicle to prevent it from slipping or falling. When using ramps, be sure the front wheels are centered squarely on the topsides; put the transmission in park; set the hand brake; and place blocks behind the rear wheels.

CAUTION! Do not use floor jacks to support the vehicle while working under it. Do not raise the vehicle onto concrete blocks, masonry or any other item not intended specifically for this use.

6. During installation, keep the work area clean. Do not allow anything to be dropped into intake, exhaust, or lubrication system components while performing the installation, as foreign objects will cause immediate engine damage upon start-up.

Tools Required:

- · Phillips head screwdriver
- Flat head screwdriver
- 7mm socket with extension and ratchet

What's Included

Item #	Description	Part #	QTY
1*	Pillar Mount Kit, Single Gauge	63345	1
	Pillar Mount Kit, Double Gauge	63346	1
	Pillar Mount Kit, Triple Gauge	63347	1
2	Owner's Manual	97694	1

*Each kit has one pillar mount. This manual covers installation for three different types of pillar mounts.



Figure 2

A-Pillar Mount Installation

1. Using a flat head screwdriver, carefully remove the 2 screw covers on either end of the factory grab handle. Use an 7mm socket with an extension to remove the 2 bolts. See **Figure 1**.

2. Remove stock pillar by starting at the top and pulling down towards thedriver seat, while sliding up towards the headliner. See **Figure 2**.

3. Remove the driver side door weather stripping near the A-Pillar, and then remove the dash side panel. See **Figure 3.**

4. Install your iDash onto the Banks pillar. Run all applicable iDash wiring up underneath where the side panel is located, and up into the ready-to-install Banks pillar. Connect all applicable wiring.







5. With everything connected Install Banks pillar by starting at the dash, aligning the tab on the Banks pillar with the slot on the iDash. See **Figure 4**.

6. Continue installing the pillar up towards the headliner, ensuring the screw hole on the pillar lines up with the stock screw location. Using a phillips screwdriver, install supplied screw into stock screw hole. See **Figure 5**.





7. Reinstall the previously removed weather stripping and side dash panel to finish the installation. See **Figure 6**.



Gale Banks Engineering 546 Duggan Avenue • Azusa, CA 91702 (626) 969-9600 • Fax (626) 334-1743

Product Information & Sales: (888) 635-4565 Customer Support: (888) 839-5600 Installation Support: (888) 839-2700

bankspower.com