

Installation Instructions Light Mounting Solutions LB, LD, LH & OR Models: D04 D10 F04 F08 F09 F11 F99

Hardware Bag Contents

2) 1 1/2" x 5/8 Bolts

- 2) 15/16 Nuts
- 2) 2" Washers

F04 & F09 Light Mounting Solutions

<u>Step 1.</u> Locate the two plastic inserts in each corner of the bumper opening, remove and discard. This will expose a factory mounting location behind the bumper on both sides. **NOTE:** The mounting locations will be a round hole through a metal plate on both sides.

<u>Step 2.</u> Match up the light bar brackets to the factory mounting holes through the bumper. Next, start a 1

1/2" x 5/8 bolt, 15/16 nut, and 2" washer and hand tighten. Repeat on other side. This concludes the installation.

F08, F99 & F11 Light Mounting Solutions

<u>Step 1.</u> Remove the four 18mm bumper bolts that are located beside the tow hooks. **NOTE:** Make sure the bumper is secure.

<u>Step 2.</u> Re-align the front bumper back with the factory bolt hole locations. Next, align the prerunner brackets with the bumper bolt locations and re-install the four 18mm bolts and hand tighten. This concludes the installation.

D04 & D10 Light Mounting Solutions <u>³/₄ Ton Only</u>

<u>Step 1.</u> Remove all four 13mm bolts from the factory tow hooks and remove hooks.

<u>Step 2.</u> Align the pre-runner/light bar bracket holes with the tow-hook bolt locations. Next, align the tow hook holes with the pre-runner/light bar bracket.

<u>Step 3.</u> Re-install the hooks using the four 13mm tow hook bolts (2 per side) and tighten. This concludes the installation.

Products Licensed to N-FAB Inc. by Fichter Designs are protected by US Patent Law and International Copy Right Law. Protected Patents include US Patent #6588783, #6874801, #7416202. Other patents and continuances pending. N-FAB product configurations also protected by International Trade Dress Law. All Designs and Patent infringements will be prosecuted to the full extent of the law.

Recommended Tools: 15/16 wrench and socket wrench