

Corona, CA 92879 Support: 951-493-7100 www.aFepower.com

Intake Kit Installation Instructions: The Universal Offroad Canister XL

			Tools Required	Part List:	1	Coupling, hump 4" x 4"
R	Kit Part #	51 /75-11061	5/16" nut driver	1 Air Filter P/N (Pro Dry S ™ 21-90036 or	2	Spacers, nylon
			10mm socket w/ ratchet or wrench	Pro-GUARD ™ 72-90036)	3	Screw, hex M6 x 1 x 12
	Make:	Universal	7/16" socket w/ ratchet or wrench	1 Housing, rotomold	5	Screw, button head M6
			Flat-head screwdriver	1 Cover, rotomold	2	Screw, hex M6 x 1 x 40
	Model:	Engine:		2 Band clamps	5	Washer, lock
	Universal	Universal		1 Snorkel	2	
g™				1 Adapter, filter	5	Washer, flat M6
				1 Cover clip	5	Washer, wavy M6
				1 Coupling, hump 4 3/4" x 3"L	2	Clamp, #072
				2 Clamp, #080	1	Coupling, reducer 4" x 3-1/2"
	1					



Complete Kit



Install button head screws and wavy washers through canister with 5-1/2" adapter.



With 10mm socket or wrench, tighten down band clamps with hardware provided. Use 1 flat, 1 lock washer per screw (*Make sure nylon spacer is* between clamp to keep from collapsing.)



Install filter into canister and tighten using 5/16" nut driver. (Use cut out slots to tighten.)



Install cover clip with hardware provided, and tighten using 10mm socket or wrench.



Line up cover clips to Dzus fasteners and secure cover.



Install your snorkel with hump coupler and clamps and tighten. (Snorkel and band clamps can be adjusted)



Two couplers are provided to use when installing your canister. (Your choice of what size to use) Check all hoses, clamps and connections periodically. Thank you for choosing aFe!

Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50000 gold oil aerosol, or aFe P/N: 90-50500 gold squeeze oil). Filter Replacement P/N: 72-90036 Pro-GUARD 7 ™ (black w/gold media) or Pro Dry S ™ P/N: 21-90036 (black w/white media) Pro Dry S ™ cleaning: see cleaning instruction sheet 06-00074