



P.O. Box 1719  
 Corona, CA 92878  
 Support: 951-493-7100  
 www.aFepower.com

## Intake Kit Installation Instructions: 2008-2010 Ford Power Stroke V8-6.4L Stage 2 Si

<b>Kit Part #</b>	54-81269 (Scoop Only)		<b>Tools Required:</b>	<b>Part List:</b>
<b>Make:</b>	FORD		13 mm socket or wrench	1 Scoop (05-01055)
			Ratchet and extension	1 7/16" trim seal (05-00072)
<b>Model</b>	<b>Year</b>	<b>Engine</b>		
Super Duty	08-10	V8-6.4L (td)		
	(F250/350/450/550)			

Step 1



**Complete stock intake.**

Step 2



Loosen the 2 bolts near passenger side battery for scoop install using 13mm socket or wrench. Attach trim seal to scoop and allign to cut-out on housing. Re-install bolts and tighten. Note: Make sure the positive battery terminal is covered with factory cap.

Step 3



Your installation is now complete. Check and retighten connections and filter after a few hours of operation. Thank You for choosing aFe!

Note: Parts subject to change. Scoop Only works with 51/54/75-81262 Intake Kit .