



# Installation Instructions

Front and Rear Bolt-On/Rugged Look Body Side Moldings

BSM001

**IMPORTANT: PLEASE READ INSTRUCTIONS ENTIRELY BEFORE INSTALLING PRODUCT.**

**Tape on product only no drilling required**

- Do not drive for four hours after install
- Do not install in weather conditions below 60 (°F)
- Wash vehicle with water, detergent and soft cloth or sponge
- Do not use petroleum based solvents or abrasives
- Do not touch exposed tape surface once liner is removed
- Ensure Body Side Moldings are firmly applied to door surface



**STEP 1:** Ensure the door areas are clean and dry in the areas where the Body Side Moldings will make contact with the door surface. Apply masking tape to front and rear doors at desired height, if a ridge line is in the door profile ensure masking tape is applied to the top edge on ridge line. Ensure the masking tape is in a straight line to assist with aligning the Body Side Moldings to the front and rear doors.

**STEP 2:** Position the Body Side Moldings onto the door to ensure an equal distance from rear back edge and front forward edge of the door, when aligned mark position with a non-permanent marker on masking tape. Ensure the correct Body Side Moldings are identified prior to installing to doors. Parts are identified on the back side of Body Side Moldings. (Left Hand Side shown above)



**STEP 3:** Peel back approximately 2" inches of protective tape liner, at alternating corners of the Body Side Molding, and fold to the outside at a 45 degree angle.  
**Important: Do not touch the exposed tape surface.**



**STEP 4:** Aligning the rear end of Body Side Moldings with the position noted in step 2. Ensure the tape liners are facing outwards and apply light pressure in the exposed tape areas. If a ridge line is in door profile, position the Body Side Molding so the top edge of part runs below and parallel with the ridge line profile. (Left Hand Front shown above)

**For Technical Support/Warranty Information please call 800-757-7075**

**EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761**



*Installation Instructions* **BSM001**  
Front and Rear Bolt-On/Rugged Look Body Side Moldings



**STEP 5:** Ensure Body Side Molding is positioned correctly on the door surface in the desired location. Slowly peel the remaining tape liner away by pulling on the exposed ends of liner and apply firm pressure around the attachment areas.



**STEP 6:** Using a clean, soft cloth, firmly rub down over the attachment areas to ensure maximum adhesion. Ensure top, bottom and ends of Body Side Moldings are rubbed down approximately 5 times using firm pressure. Ensure no gapping is evident along top, bottom and ends of Body Side Moldings.



**STEP 7:** Remove masking tape from door surface. Repeat the previous steps for opposite side of vehicle to complete installation of Body Side Moldings. (Left Hand Side shown above)

**For Technical Support/Warranty Information please call 800-757-7075**

**EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761**