

## CONTENTS

- (2) front Stepshields
- (2) extended cab Stepshields
- (4) alcohol pads
- (1) instruction sheet

**IMPORTANT:** Read all instructions carefully before beginning installation. Identify the front and extended cab Stepshields. **The Extended Cab Stepshields must be installed first and a trial fit is recommended.** The ideal installation temperature is between 65°-110° F.

### STEP 1: Extended Cab Stepshield Installation

Open the front door and extended cab door. Clean the door sills of the vehicle where both Stepshields will mount with an alcohol pad. Then wipe dry with a clean cloth. See **FIGURE 1**

### STEP 2

To reduce the risk of tape contamination due to improper positioning, expose only 2" of tape from each end of the Stepshield by peeling back liner. Be sure the tape liner can be easily accessed later. **Remove the rubber plug from the extended cab sill.** See **FIGURE 2**

### STEP 3

Align the Stepshield with the previously cleaned door sill. Gently press the exposed areas of the tape against the door sill and verify position.

### STEP 4

With the Stepshield in its final position, remove the remainder of the liner by pulling on the free ends. Press firmly along the surface of the Stepshield to ensure proper adhesion of the tape to the door sill. See **FIGURE 3**

Repeat the above installation procedure for opposite side Extended Cab Stepshield.

### STEP 5: Front Stepshield Installation

Install the front Stepshields flush against the previously installed Extended Cab Stepshield. See **FIGURE 3**

Repeat the above installation procedure for opposite side front Stepshield.

