



**Elite Breather 90° side mounting
Part #4201 & #4211
INSTALLATION INSTRUCTIONS**

INSTALLATION INSTRUCTIONS:

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation
Part #4201 & 4211

Edelbrock Corporation
2700 California St., Torrance, CA 90503
Tech Line: (800) 416-8628; Office: (310) 781-2222
E-Mail: Edelbrock@Edelbrock.com

Rev. 1/09 - AJ/mc
Brochure #63-4201



**Elite Breather 90° side mounting
Part #4201 & #4211
INSTALLATION INSTRUCTIONS**

INSTALLATION INSTRUCTIONS:

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation
Part #4201 & 4211

Edelbrock Corporation
2700 California St., Torrance, CA 90503
Tech Line: (800) 416-8628; Office: (310) 781-2222
E-Mail: Edelbrock@Edelbrock.com

Rev. 1/09 - AJ/mc
Brochure #63-4201



**Elite Breather 90° side mounting
Part #4201 & #4211
INSTALLATION INSTRUCTIONS**

INSTALLATION INSTRUCTIONS:

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation
Part #4201 & 4211

Edelbrock Corporation
2700 California St., Torrance, CA 90503
Tech Line: (800) 416-8628; Office: (310) 781-2222
E-Mail: Edelbrock@Edelbrock.com

Rev. 1/09 - AJ/mc
Brochure #63-4201



**Elite Breather 90° side mounting
Part #4201 & #4211
INSTALLATION INSTRUCTIONS**

INSTALLATION INSTRUCTIONS:

1. Select a desired location for breather. Using gasket as a template, mark valve cover for mounting holes and 10 to 14 additional holes in breather area.
2. Using a 17/64" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2009 Edelbrock Corporation
Part #4201 & 4211

Edelbrock Corporation
2700 California St., Torrance, CA 90503
Tech Line: (800) 416-8628; Office: (310) 781-2222
E-Mail: Edelbrock@Edelbrock.com

Rev. 1/09 - AJ/mc
Brochure #63-4201