



INSTALLATION INSTRUCTIONS
for Cast Aluminum Competition Breather
CATALOG #4203

INSTALLATION INSTRUCTIONS:

1. Select desired location for breather. Avoid locating the breather directly above a rocker arm to prevent excessive oil loss. Using the gasket as a template, mark valve cover for mounting holes and 4 to 6 additional holes in breather area.
2. Using an 11/32" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2008 Edelbrock Corp.
Catalog #4203

Brochure #63-4203
Rev. 12/08 - AJ/mc



INSTALLATION INSTRUCTIONS
for Cast Aluminum Competition Breather
CATALOG #4203

INSTALLATION INSTRUCTIONS:

1. Select desired location for breather. Avoid locating the breather directly above a rocker arm to prevent excessive oil loss. Using the gasket as a template, mark valve cover for mounting holes and 4 to 6 additional holes in breather area.
2. Using an 11/32" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2008 Edelbrock Corp.
Catalog #4203

Brochure #63-4203
Rev. 12/08 - AJ/mc



INSTALLATION INSTRUCTIONS
for Cast Aluminum Competition Breather
CATALOG #4203

INSTALLATION INSTRUCTIONS:

1. Select desired location for breather. Avoid locating the breather directly above a rocker arm to prevent excessive oil loss. Using the gasket as a template, mark valve cover for mounting holes and 4 to 6 additional holes in breather area.
2. Using an 11/32" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2008 Edelbrock Corp.
Catalog #4203

Brochure #63-4203
Rev. 12/08 - AJ/mc



INSTALLATION INSTRUCTIONS
for Cast Aluminum Competition Breather
CATALOG #4203

INSTALLATION INSTRUCTIONS:

1. Select desired location for breather. Avoid locating the breather directly above a rocker arm to prevent excessive oil loss. Using the gasket as a template, mark valve cover for mounting holes and 4 to 6 additional holes in breather area.
2. Using an 11/32" drill bit, drill holes in valve cover.
3. Clean all chips and burrs from cover.
4. Install gasket and breather with bolts, nuts and washers supplied.

©2008 Edelbrock Corp.
Catalog #4203

Brochure #63-4203
Rev. 12/08 - AJ/mc