Intake Manifold Gaskets & Cylinder Head Gasket Kits



INSTALLATION SUPPLEMENT

- We recommend the use of Edelbrock Gasgacinch (Part #9300) on the intake manifold mounting surface of the cylinder head, and on the cylinder head side of the Intake Manifold Gaskets, in order to hold the gasket in place on the cylinder head and to ensure a proper seal. Follow the instructions on the Gasgacinch can for the proper application procedure. DO NOT USE Gasgacinch on cylinder head gaskets.
- Intake Manifold End seals are not included with Intake Manifold Gaskets. In applications that normally use intake manifold
 end seals, use a 1/4" bead of RTV silicone in place of end seals (unless otherwise noted in the installation instructions for
 the individual intake manifold being used). Make sure the bead overlaps the corners of the intake gaskets.
- Using a thin film of RTV silicone around any water jacket openings in the gasket (on the intake manifold side only) will help ensure a proper seal around the water jacket openings.

Edelbrock Corporation
2700 California Street • Torrance, CA 90503
Tech Line: 1-800-416-8628
Tech E-Mail: Edelbrock@Edelbrock.com

©2004 Edelbrock Corp. Rev. 8/04 Cyl. Head Gasket Kits & Intake Gaskets Brochure No. 63-0287



Intake Manifold Gaskets & Cylinder Head Gasket Kits

INSTALLATION SUPPLEMENT

- We recommend the use of Edelbrock Gasgacinch (Part #9300) on the intake manifold mounting surface of the cylinder head, and on the cylinder head side of the Intake Manifold Gaskets, in order to hold the gasket in place on the cylinder head and to ensure a proper seal. Follow the instructions on the Gasgacinch can for the proper application procedure. DO NOT USE Gasgacinch on cylinder head gaskets.
- Intake Manifold End seals are not included with Intake Manifold Gaskets. In applications that normally use intake manifold end seals, use a 1/4" bead of RTV silicone in place of end seals (unless otherwise noted in the installation instructions for the individual intake manifold being used). Make sure the bead overlaps the corners of the intake gaskets.
- Using a thin film of RTV silicone around any water jacket openings in the gasket (on the intake manifold side only) will help ensure a proper seal around the water jacket openings.

Edelbrock Corporation
2700 California Street • Torrance, CA 90503
Tech Line: 1-800-416-8628
Tech E-Mail: Edelbrock@Edelbrock.com