



Platinum Series Bug Shield  
Non Drill BUG DEFLECTOR

Installation Instruction: M

The installation of this bug shield can be done by a single individual, but it is not recommended.

- 1) Thoroughly clean front hood area.
- 2) Open Hood. Some vehicles have a black plastic insert that has to be removed before installation. With a screw driver CAREFULLY remove insert to reveal the remaining bolts.
- 3) Remove the bolts from the two extended grill brackets using a 10mm socket.
- 4) Then remove the bolts from the rest of the grill. Remove grill.
- 5) Install the shield into the existing holes with the two screws provided. Before you screw them in place check to make sure it is centered by "eyeing" the part.
- 6) Position the bugshield in the center of the hood and reinstall the two extended grill brackets first and then the remaining bolts.

DO NOT OVER TIGHTEN BOLTS.

- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 washer, 2- 5/16 x 1/2 BAS screws



Platinum Series Bug Shield  
Non Drill BUG DEFLECTOR

Installation Instruction: M

The installation of this bug shield can be done by a single individual, but it is not recommended.

- 1) Thoroughly clean front hood area.
- 2) Open Hood. Some vehicles have a black plastic insert that has to be removed before installation. With a screw driver CAREFULLY remove insert to reveal the remaining bolts.
- 3) Remove the bolts from the two extended grill brackets using a 10mm socket.
- 4) Then remove the bolts from the rest of the grill. Remove grill.
- 5) Install the shield into the existing holes with the two screws provided. Before you screw them in place check to make sure it is centered by "eyeing" the part.
- 6) Position the bugshield in the center of the hood and reinstall the two extended grill brackets first and then the remaining bolts.

DO NOT OVER TIGHTEN BOLTS.

- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2- 5/16 washer, 2- 5/16 x 1/2 BAS screws