

READ THIS NOW!

Your truck should look like the one shown. If you think you are missing any parts, think that this part number i not for your truck or have any installation question, cc our customer service department at toll free: **800-265-8137** or locally **905 849-3633**. Other ways to reach BACKRACK: Fax **905-849-4116** email: **techsupport@backrack.ca**



The BACKRACK LP Kit is secured to your truck with carriage bolts that require drilling of the truck rails. The BACKRACK assembly sits on the bed rails of your truck and is secured with these bolts. If your truck has a BEDLINER we suggest you remove it to drill and install the bolts

Place Low Profile Bracket into postion on the truck as shown. Ensure that the bracket is firmly against the side and front of the bed as shown. Mark the mount holes on the bed of your truck.



FOR MORE INFORMATION SCAN HERE!





****USE EXTREME CAUTION WHEN DRILLING****

Improper drilling can cause damage to your truck bed and/or cab. Drill the holes by frist drilling a pilot hole (1/8") and then drilling to 7/16"



1

