INSTALLATION INSTRUCTIONS 2-1/16" Replacement Pillar F-150 15+ / Super Duty 17+ w/Speaker

2650-1933-77



Read through directions completely before starting installation.

1) Open factory handle covers and remove bolts w/10mm socket



- 2) Detach factory pillar by pulling towards yourself, then slide upwards towards headliner to release tabs from dash.
- 3) Unclip wire harness from speaker.

4) Remove factory speaker and grill. Install into pillar using supplied 4-40 screws



7) Insert screw into pillar, slide spacer over screw, align screw with snap nut and attach



Auto Meter Gauge Works Three Year Limited Warranty

AutoMeter Products, Inc. warrants to the consumer that all AutoMeter High Performance products purchased from an Authorized AutoMeter Reseller will be free from defects in material and workmanship for a period of twelve (12) months from date of the original purchase. Products that fail within this 12 month warranty period will be repaired or replaced at AutoMeter's option, when determined by AutoMeter that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the AutoMeter High Performance product and the necessary labor done by AutoMeter to effect the repair or replacement of the AutoMeter High Performance product. In no event shall AutoMeter's cost to repair or replace an AutoMeter High Performance Product under this warranty exceed the original purchase price of the AutoMeter High Performance Product. Nor shall AutoMeter Products, Inc. be responsible for special, incidental or consequential damages or costs incurred due to the failure of an AutoMeter High Performance Product. This warranty applies only to the original purchaser of the AutoMeter High Performance Product and is non-transferable. This warranty also applies only to AutoMeter High Performance Products purchased from an Authorized AutoMeter Reseller. All implied warranties shall be limited in duration to the said 12 month warranty period. Breaking the instrument seal, improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. AutoMeter disclaims any liability for consequential damages due to the breach of any written or implied warranty on all products manufactured by AutoMeter Products, Inc. For a comprehensive listing of Un-Authorized AutoMeter Resellers please visit www.autometer.com/autometerlocator/index/unauthorized.

5) Install supplied snap nut into lower portion of slot



taken NOT to

- 6) Connect speaker wire, insert bottom of pillar into dash area first.

NOTE: Caution must be over-tighten screw!