

Bill of Materials		
Part No.	Description	Qty
KU70039	Winch Isolator	1

INSTRUCTIONS

- 1. Switch winch to Free Spool and remove cable from winch
- 2. Slide cable through slot on winch isolator, ensuring isolator is facing direction indicated in picture.
- 3. Attach the winch cable to the drum and load cable as explained by the manufacturer's owners manual. DO NOT allow cable to pull through the isolator.
- 4. Using the winch safety strap snug the winch hook into the isolator.
- 5. Isolator is designed to rest between the rollers. It does not attach to them.

WARRANTY NOTE

DO NOT USE THE ISOLATOR AS A WINCH GUIDE

WARNING

This vehicle has been modified to enhance its performance. The steering, braking and handling of this vehicle will differ from standard passenger cars and trucks; this vehicle handles differently from an ordinary vehicle in driving conditions which may occur on streets, highways and off road. Avoid unnecessary abrupt maneuvers, sudden stops, sharp turns and other driving conditions that could cause loss of control, possibly leading to a roll over or other accident that could result in serious injury or death to driver and passengers.

If larger tires are installed the speedometer will read lower than the vehicles actual speed.

DRIVE WITH CARE, REDUCE SPEED AND WEAR SEAT BELTS AT ALL TIMES.

This kit should be installed by a professional mechanic.

