

advanced FLOW engineering

Dynamic Air Scoop D.A.S

Instruction Manual P/N: 54-73004-S

Make: Ford Model: Super Duty F-250/F-350 Year: 2008-2010 Engine: V8-6.4L (td) Power Stroke



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.

Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Scoop, Rotomold	05-73004B3

Installation will require the following tools:
13mm socket, socket wrench.

Warranty Information available at: <https://afepower.com/contact#warranty>

Emissions Disclaimer:

This product is not currently CARB exempt and is not available for purchase in California or for use on any vehicle registered with the California Department of Motor Vehicles.






Figure A

Refer to Figure A for Step 1

Step 1: Remove the two OE bolts ①.



Figure B

Refer to Figure B for Steps 2-3

Step 2: While holding the scoop snug against the aFe housing, align the two holes on the scoop with the two OE holes on the truck's crossmember.

Step 3: Secure the scoop with the two bolts removed in Step 1. ②

Your installation is now complete. Thank you for choosing aFe Power!



Page left blank intentionally

Page left blank intentionally



advanced FLOW engineering, inc.
252 Granite Street Corona, CA 92879
<https://afepower.com/contact>