

advanced FLOW engineering

Dynamic Air Scoop

Instruction Manual P/N: 56-70033S / 56-70059S

Make: KIA

Model: Telluride

Year: 20-22

Engine: V6-3.8L



- Please read the entire instruction manual before proceeding.
- Ensure all components listed are present.
- If you are missing any of the components, call customer support at 951-493-7185.
- Ensure you have all necessary tools before proceeding.
- Do not attempt to work on your vehicle when the engine is hot.
- Retain factory parts for future use.

Label	Qty.	Description	Part Number
A	1	Scoop, Rotomold	05-5670033B3
B	2	Push Clips	03-50773

Installation will require the following tools:

Panel popper tool or small flat-blade screwdriver

Warranty Information available at: <https://afepower.com/contact#warranty>







Figure A

Refer to Figure A for Step 1

Step 1: Using a panel popper or a flat-blade screwdriver, remove the push clips holding in the factory scoop in the front of the engine bay.

**Figure B****Refer to Figure B for Steps 2**

Step 2: Lift the front part of the factory scoop and pull it toward the front of the vehicle.



Figure C

Refer to Figure C for Steps 3

Step 3: If installed, remove the TAKEDA plug from the TAKEDA housing.

**Figure D****Refer to Figure D for Step 4**

Step 4: Install the TAKEDA DAS by first inserting the outlet to the housing, then lining up the inlet of the scoop to the mounting area in the front of the engine bay.



Figure E

Refer to Figure E for Step 5

Step 5: Install the push clips into the front part of the scoop as shown.



Figure F

Refer to Figure F for Installation Completion

Your installation is complete! Thank you for choosing Takeda!



Page left blank intentionally



Page left blank intentionally.



advanced FLOW engineering, inc.

252 Granite Street Corona, CA 92879

<https://afepower.com/contact>

ZS 9/14/22